


# Datalogic QD2100 Scanner Basic Options

Reset to Factory Defaults



Enable RS-232 COM Emulation



Enable Stand Mode

